

IMPORTANT: To prepare you for visiting SteriPack's Cleanroom facilities please read the following notes.

GOWNING AREA

Visitors will be asked to sign the Visitors Log Book, located at each entrance to the cleanroom. This document will also have a copy of the Gowning Rules. You will be informed of the gowning procedures on arrival to the cleanroom changing facility. Before entering the cleanroom you will be provided with the appropriate clothing in the changing area.

Only approved clothing/accessories may be worn:

- CE hats
- coats/jumpsuits
- safety shoes
- shoe covers
- beard Covers

Cleanroom attire:

- Footware must cover the foot and must be worn with socks or hosiery. **NO** sandals or open-toed shoes allowed
- Shoes must be clean and in a style to allow coverage by protective shoe covers

NOT ALLOWED

- Mobile phones can only be answered in the Office Area
- Newspapers / Books / Magazines are confined to work related items or Operating Manuals.
- Food & Drink
- Chewing Gum
- Jewellery is restricted to the following:
 - Rings- Plain Bands (no stones)
 - Watches- Tight straps with no safety chain
 - Earrings- Sleepers or studs
 - Necklaces- must be contained within clothing
 - Facial piercings to be covered with blue plasters
- Nail Polish/False Nails
- Powders
- Makeup
- Tippex , pencils or erasers

If you have a cold or illness, which may be contagious please report to a member of staff before entering the cleanroom.

In the meantime, if you have a personal request or enquiry before you visit our facility you can contact Linda Gilsean at lg@steripack.ie or alternatively call +353 57 933 1888.